

INSTALLATION INSTRUCTIONS

Polaris RZRXP Front Brush Guard



Read instructions and view illustrations before beginning.

Need help with your installation?



sales@superatv.com



www.superatv.com



1-812-574-7777



8:00am - 9:00pm EST M-Th 8:00am - 7:00pm EST Friday

9:00am - 2:00pm EST Saturday

Thank You



Liability Statemen

SuperATV's products are designed to best fit users ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory, or aftermarket, parts will void any warranty provided by SuperATV and is not recommended. SuperATV's products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV to verify that they will work together.

Although SuperATV has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV urges operators and occupants to wear a helmet and appropriate riding gear at all times.


By purchasing and installing SuperATV products, user agrees that should damages occur, SuperATV will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.


SuperATV will warranty only parts provided by SuperATV. Any damage or problems with OEM housings, bearings, seals, or other manufacturers products will not be covered by SuperATV. SuperATV parts and products are not warrantied if item was not installed properly, misused, or modified.

Kit Contents

Item	Description	Qty
Α	Ноор	1
В	Short Grill	1
С	Front Bumper	1
D	Front Bracket	1
E	Left Bracket	1
F	Rear Bracket	1
G	Right Bracket	1


Item	Description	Qty
Н	M8 Flat Washers	18
J	M8-1.25 x 25mm Lg. Carriage Head Bolts	4
K	M8-1.25 x 30mm Lg. HHCS	8
L	M8-1.25 Nylock Nuts	18
М	M8-1.25 x 20mm Lg. SHCS	4
N	5/16" x 3/4" Lg. Self Tapping Screws	2
Р	M8-1.25 x 25mm Lg. HHCS	2





Do not tighten hardware completely unless noted. Keep stock hardware for reuse.

- 1. Remove stock Bumper. See Figs. 1 1b.
- 2. Remove stock Grill Insert. See Fig. 1c.
- 3. Install Hoop (A) to Front Bumper (C) with M8-1.25 x 20mm Lg. SHCS (M), M8 Flat Washers (H), and M8-1.25 Nylock Nuts (L); *tighten hardware*. See Figs. 2 2a.
- 4. Install Short Grill (B) to Bumper with stock hardware; *tighten hardware*. See Fig. 3.
- Locate (2) mounting holes shown in Fig. 4. and install Rear Bracket (F) to machine with M8-1.25 x 25mm Lg. HHCS (P), M8 Flat Washers (H), and M8-1.25 Nylock Nuts (L). See Figs. 4 4a.
- 6. Reinstall stock Bumper with stock hardware.
- 7. Install Right Bracket (G) and Left Bracket (E) to machine with 5/16" x 3/4" Lg. Self Tapping Screws (N). See Fig. 5.
- 8. Install Front Bracket (D), as shown in Fig. 6, with M8-1.25 x 30mm Lg. HHCS (K), M8 Flat Washers (H), and M8-1.25 Nylock Nuts (L). See Figs. 6 6a.
- Install Front Bumper (C) to Front Bracket (D) with M8-1.25 x 25mm Lg. Carriage Head Bolts (J), M8 Flat Washers (H), and M8-1.25 Nylock Nuts (L). See Fig. 7.
- 10. Align to machine and tighten all hardware.












(installation illustrations continued)



















Item	Description
Н	M8 Flat Washers
L	M8-1.25 Nylock Nuts
М	M8-1.25 x 20mm Lg. SHCS
N	5/16" x 3/4" Lg. Self Tapping Screws
Р	M8-1.25 x 25mm Lg. HHCS

(installation illustrations continued)











PARTS REFERENCE

Item	Description
Α	Ноор
В	Short Grill
С	Front Bumper
D	Front Bracket
E	Left Bracket
F	Rear Bracket
G	Right Bracket
Н	M8 Flat Washers
J	M8-1.25 x 25mm Lg. Carriage Head Bolts
K	M8-1.25 x 30mm Lg. HHCS
L	M8-1.25 Nylock Nuts
М	M8-1.25 x 20mm Lg. SHCS
N	5/16" x 3/4" Lg. Self Tapping Screws
Р	M8-1.25 x 25mm Lg. HHCS